

GT-526 Handheld Particle Counter



The Affordable Six Channel Solution

Bench Unit Performance in the Palm of Your Hand

The GT-526 is a full-featured, battery-operated, portable laser particle counter that provides the functionality of a bench unit with the convenience of a handheld! It can datalog particle counts continuously or send them to a network.

Six Particle Channels Displayed

Six preset particle channels (0.3, 0.5, 0.7, 1.0, 2.0, 5.0) show cumulative counts in real time, with selectable count units.

Menu-Driven Command Set for Out of the Box Operation

A simple touch of a button sets sample time, and basic setup parameters such as date/time and communications settings. Remote operation via RS-232 or RS-485 communications port allows extensive control, including all front-panel operations.

Flexible Data Interfaces

Stores up to 8,000 records for printer output, Excel[®] formatted output, or networked datalogging via the included single computer software (Comet).

Temperature and Relative Humidity Option

A plug-and-play option that immediately adds ambient temperature and relative humidity capabilities to the displayed and logged data.



Applications:

- | | |
|-------------------------|--------------------|
| Controlled Environments | Filter Testing |
| Indoor Air Quality | Compliance Testing |
| Process Control | Emission Sourcing |
| HVAC Applications | Remote Sampling |
| | QA Programs |

**Whatever your particular needs,
the right choice is only natural.**

